


# Accessories

## Seismic Bracket



Two required per unit  
(With the exception of the Phoenix  
Compact which requires one per  
unit)

